

# High Frequency Connectors and Adaptors

## Connectors



SMA Plug



SMA Socket



SMA R/P Plug



SMA R/P Socket



TNC Plug



TNC Socket



TNC R/P Plug



TNC R/P Socket



N Plug



N Socket



uFI Plug



uFI Socket



MMCX Plug



MMCX Socket



FME Plug



FME Socket

## Adaptors



SMA RP Plug  
to N Female



SMA RP Plug  
to N Male



SMA RP Socket  
to N-male



RP-SMA Female  
to N-Female



N-Female  
to N-Female



N-Male  
to N-male



SMA Plug  
to FME Plug



SMA R/P Plug  
to FME Plug



FMEMale  
to SMB Male



N-Female  
to SMA-Male

\* Pictures are not to scale