


QUICK PROGRAMMING GUIDE

905-ZA (Double filter)



Press any key to turn on the PS-003.



Press the **F** key followed by **SERIE+** to set the programmer to select the series to be programmed. Use the arrows to select **SERIE 905 ZA**, then press **▼**.



Pointing at the amplifier PA-320, press transmit **T** for the amplifier to activate the programming mode.



Using the arrows, select the model which you intend to program: **ZA-411 Double filter**.
* If no model is selected, you will go straight to the menu for the automatic adjustment of levels.
Press the programming button **PRG** of the first ZA.



For filter 1, use the arrows to select analogical mode, for analogical or digital channels, for digital channels. If a multichannel filter is used and if any of the channels is analogical, select analogical mode. Then press transmit **T**.



For filter 1, use the arrows or the numeric keypad to select the channel of filter 1. For multichannel filter, press the **⊙** key and use the arrows to increase or decrease the width of the filter. Then press transmit **T**. Press **⊙** to deactivate the filter.



The same as for filter 1



The same as for filter 1

Press the programming button of the next module and go back to the step Mode: F1, or, if you have already programmed all the modules, continue with the following steps.



Press transmit **T** to automatically adjust the output levels of all the modules.



Use the arrows to select the amount by which the level of filter 1 is increased or decreased. Each time you press the **T** key, the output level will increase or decrease by this amount.



The same as the previous step for filter 2.



Select the standard of the country or the introduction of channels by frequency.

Note 1: You can send all the data to the module in a single go by pressing **F + COPY**.

Note 2: Once the programming has been completed, regulate the output level of the PA-320.